

Ref. No.	Part No.	Description		No. Remarks
		ENGINE AND GEARBOX MOUNTING (contd.	.)	
	NH2008	Nut, mounting to frame		4
	WL0208	Spring washer, mounting to frame		4
	104086	Engine mounting, rear		1
	ВНІПІ	Bolt, mounting to box extension		2
	NH2011	Nut, mounting to box extension		2
	WL0211	Spring washer, mounting to box extension		2
	NH2010	Nut, mounting to frame		2
	WL0210	Spring washer, mounting to frame		2
	BH0858	Bolt, gearbox to engine		6
	WL0208	Spring washer, gearbox to engine		9
	NH2008	Nut, gearbox to engine		3
		OVERDRIVE GEARBOX DETAILS		
		(These details are required only when cars are fitted with overdrive)		
	400168	Gearbox and overdrive unit		1
	300623	Overdrive unit		I For details see ove
	101555	Coupling lever, selector to lever		2 drive section uni
	101546	Abutment bracket assembly		1
	101546	Abutment bracket assembly Pawl assembly, abutment bracket		1
	101169	Pawl assembly, abutment bracket		
	101169 101673 NL2208	Pawl assembly, abutment bracket  Pawl spring, pawl abutment bracket		
	101169 101673 NL2208	Pawl assembly, abutment bracket  Pawl spring, pawl abutment bracket  Slotted nut, pawl assembly to abutment bracket		
	101169 101673 NL2208 WP0008	Pawl assembly, abutment bracket  Pawl spring, pawl abutment bracket  Slotted nut, pawl assembly to abutment bracket  Plain washer, pawl assembly to abutment bracket		
	101169 101673 NL2208 WP0008 PC0008	Pawl assembly, abutment bracket  Pawl spring, pawl abutment bracket  Slotted nut, pawl assembly to abutment bracket  Plain washer, pawl assembly to abutment bracket  Cotter pin, pawl assembly to abutment bracket		

Ref. No.	Part No.	Description		No. Off	Remarks
		OVERDRIVE GEARBOX DETAILS (			
	BH0757	Bolt, abutment bracket and rear selector bush to	gearbox	. 2	
	BH0756	Bolt, abutment bracket and rear selector bush to	o gearbox	. 1	
	WL0207	Spring washer, abutment bracket and rear sele to gearbox	ctor bush	. 3	
	101939	Overdrive control lever assembly		. 1	
	101071	Trunnion, overdrive lever		. 1	
	NL2207	Slotted nut, trunnion to lever assembly		. 1	
	WP0007	Plain washer, trunnion to lever assembly		. 1	
	PC0007	Cotter pin, trunnion to lever assembly		. 1	
	101574	Bolt, overdrive lever to overdrive unit		. 1	
	NL2207	Slotted nut, overdrive lever to overdrive unit		. 1	
	WP0007	Plain washer, overdrive lever to overdrive un	it	. 1	
	PC0007	Cotter pin, overdrive lever to overdrive unit		. 1	
	500558/1	Speedo cable, inner		. 1	
	500558/0	Speedo cable, outer		. 1	
	600395	Grommet, speedo cable		. 1	
	59191	Clip, speedo cable to frame		. 1	

Ref. No.	Part No.	Description	No. Off	Remarks	
		OVERDRIVE UNIT DETAILS			
	300623	Overdrive unit assembly, comprising:	1		
2	500654	Front cover plate	1		
3	500644	Paper joint, front cover plate	1		
4	103269	Bolt, front casing to synchro. box	6		
5	500620	Drain plug	1		
6	500641	Washer, for drain plug	1		
7	103270	Bolt, for filter	. 1		
8	500619	Filter	. 1		
9	500585	Plug, for pump body	. 1		
10	500584	Pump body	. 1		
11	500633	Pump spring	. 1		
12	500597	Pump plunger sub-assembly	. 1		
13	500587	Bridge piece, for clutch operation	. 2		
14	500627	Cam	. 1		
15	500578	Stud	. 3		
16	500676	Operating piston sub-assembly	. 1		
17	500562	Main casting sub-assembly	. 1		
18	500576	Stud	. 2		
19	103267	Stud	. 2		
20	500570	Welch washer	. 1		
21	500592	Valve spring	. 1		
22	500568	Copper washer	. 1		
23	500582	Valve plug	. 1		
24	500579	Stud	. 2		
25	500604	Accumulator piston sub-assembly	. 1		
26	500634	Spring, accumulator, large	. 1		
27	500635	Spring, accumulator, small	. 1		

Ref. No.	Part No.	Description No. Remark
		OVERDRIVE UNIT DETAILS (contd.)
28	500645	Paper joint, for side cover
29	500657	Side cover
30	500571	Collar, valve operating shaft
31	500631	Clutch spring, long 4
32	500632	Clutch spring, short 4
33	500588	Spacing washer
34	500622	Brake ring
35	500660	Clutch thrust ring sub-assembly
36	500661	Clutch sliding member sub-assembly
37	500662	Sunwheel sub-assembly
38	500612	Thrust washer 2
39	500629	Pin, uni-directional clutch to cage
40	500659	Inner member, for uni-directional clutch
41	500656	Cage, for uni-directional clutch
42	500630	Spring, for uni-directional clutch cage
43	500613	Thrust washer
44	500602	Annulus sub-assembly
45	SP75G	Ball bearing
46	500623	Spacing washer
47	SP75G	Bearing, rear
48	58958	Oil seal
49	500655	Rear casing sub-assembly
50	500658	Operating valve
51	500591	Plunger, for ball valve 1
52	500577	Stud 2
53	500610	Thrust washer
54	500624	Spacing washer

Ref.	Part No.		Desc	cription				No. Off	Rema	arks
		OVERDRI	VE UN	IT DET	AILS (c	contd.)				
55	500639	Steel roller						12		
56	500756	Stud					·	4		
57	103268	Set screw, &"						2		
8	500593	Taper pin						3		
9	500594	Oil seal						1		
60	500636	Seeger circlip						1		
16	500637	Seeger circlip						1		
2	500640	Ball bearing			***			1		
		•								
						* .				
							t.			
						-			+	